

IS-HC04-22-D rev.00 SECURE RECESSED DRYWALL 1X2, 2X2, 1X4, 2X4 INSTALLATION INSTRUCTIONS

<u>NOTE</u>

The following instructions provide general guidelines for product installation. These instructions apply to the 1x2, 2x2, 1x4 and 2x4 sized fixtures. For additional information consult the applicable electrical codes or contact factory directly for support before attempting anything with uncertainty.


WARNING


Risk of fire and electrical shock. **DISCONNECT POWER AT ELECTRICAL PANEL** before installing or servicing this product.

GENERAL SAFETY INSTRUCTIONS

- Read all instructions prior to installing this fixture.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- All wiring must be performed by a qualified electrician in accordance with national and local building and electrical codes.
- This fixture must be suitably grounded for your protection against shock hazards and to assure proper operation.
- Make sure that the power source conforms to the requirements of this fixture.

CEILING OPENING SIZE		
FIXTURE	T-BAR WIDTH	T-BAR LENGTH
1' x 2'	309.6 mm (12-3/16")	616 mm (24-1/4")
2' x 2'	614.4 mm (24-3/16")	616 mm (24-1/4")
1' x 4'	309.6 mm (12-3/16")	1225.6 mm (48-1/4")
2' x 4'	614.4 mm (24-3/16")	1225.6 mm (48-1/4")






PARTS LIST: 1X2

- A. Back of Luminaire enclosure
- B. T-bar mounting bracket
- C. Door
- D. Driver access panel


Specifications and design subject to change without notice. <u>www.metalumen.com</u>

Page 2 of 5 INSTALLATION INSTRUCTIONS

Ideas brought to light




Ideas brought to light



D. Driver access panel


WIRING DIAGRAM



Metalumen


Ideas brought to light


INSTALLATION STEPS




CEILING OPENING SIZE		
FIXTURE	OPENING WIDTH	OPENING LENGTH
1' x 2'	12-3/16"	24-1/4"
2' x 2'	24-3/16'	24-1/4"
1' x 4'	12-3/16"	48-1/4"
2' x 4'	24-3/16"	48-1/4"


Step 2: Create ceiling opening as per chart






<u>Step 4</u>: Once the cut out is made, insert drywall frame kit and secure bracket to bracing using appropriate fasteners (by others). Use shims to prevent bracket joints from opening.






Ideas brought to light

Metalumen





Specifications and design subject to change without notice. www.metalumen.com