

IS-SCENE-22-PP-RS rev.01 SCENE PENDANT REMOTE SURFACE CANOPY 2X2 INSTALLATION INSTRUCTIONS

NOTE


The following instructions provide general guidelines for product installation. These instructions apply to the 2x2 sized fixtures. For additional information consult the applicable electrical codes or contact factory directly for support before attempting anything with uncertainty.

WARNING

Risk of fire and electrical shock. **DISCONNECT POWER AT ELECTRICAL PANEL** before installing or servicing this product.

GENERAL SAFETY INSTRUCTIONS

- · Read all instructions prior to installing this fixture.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- All wiring must be performed by a qualified electrician in accordance with national and local building and electrical codes.
- This fixture must be suitably grounded for your protection against shock hazards and to assure proper operation.
- Make sure that the power source conforms to the requirements of this fixture.
- This product has accessible output terminals. Based on Canadian Electrical Code for class 2 circuits, this product requires installation in Restricted Access Area, so that no live parts are accessible to unauthorized persons.





PARTS LIST: 2X2 FIXTURE

- A. Surface Canopy Base
- B. Canopy Cover
- C. Powered Aircraft Cable
- D. Luminaire
- E. Aircraft Cable Gripper




WIRING DIAGRAM







INSTALLATION STEPS




<u>Step 1</u>: Remove fixture and all supplied parts from packaging. **DO NOT REMOVE** the protective film from the front surface of the fixture.



<u>Step 2</u>: Secure Hex-Box (supplied by others) to a structure of suitable strength to support the fixture.




<u>Step 3</u>: Disassemble Surface canopy by first unscrewing the 4 end caps in the middle of the fixture and then the 4 flat head screws at the corners. Lower the canopy cover.




<u>Step 4:</u> Detach the canopy baseplate from the mounting bracket by unscrewing the 2 screws. Lower the baseplate.







<u>Step 5</u>: Attach surface canopy base to ceiling with screws (supplied by others)




Step 6: Wire integral driver to line voltage



<u>Step 7</u>: Re-attach canopy baseplate to the canopy mounting bracket with flat head screws.



<u>Step 8</u>: Secure canopy cover to the surface canopy using 4 end caps and 4 corner screws.



Step 9: Remove protective film from the front surface of the light fixture when installation is completed.



MAINTENANCE STEPS

Required Tools:





TENSITE / EXTENDED VES

Important: Use clean gloves to avoid adding oil/dirt to optics. Avoid scratching optics by using installation tools with soft plastic rounded edges.

To Clean the Optics:

- Gently wipe down the optics with a clean, dry cloth to remove any dust and light residues.
- For heavier smudges, spray clean cloth with mild soap and water solution and gently wipe optics surface.

WARNING: Hard wiping and abrasive cloths will scratch the optics. DO NOT USE cleaning products containing alcohol or acetone which will damage the optics.