

CLEANING TIPS

ezoBord products have been developed to be easily cleaned and maintained. If your ezoBord product becomes dirty, simply remove dust and dirt with a stiff plastic bristle brush or vacuum, ensuring vacuum hose is clean. Distilled water can be used to remove stains. Always use a soft, lint free cloth to blot dry. If directly applying water to the product is not practical, a steam cleaner can be used ensuring not to overheat the material.

